



DV-INabler

DV-IN Enabler for Camcorders

DV-INabler activates the DV-IN functionality on your camcorder to allow you to export video footage from your computer to your camera. Simply connect DV-INabler to the COM port of your camera, press the button and a few seconds later DV-IN will be enabled on your camera! Now, you will be able to import your video footage to your computer, edit it with a DV application and export it back to your DV camcorder!

If you wish to remove the enabler code that DV-INabler loads to your camera, simply plug in the device and press the button for 10 seconds. Your camera will be reverted to its original state without any trace of DV-INabler's modification. Another feature of DV-INabler is its ability to act as a record and pause button for your camera.

Canon Compatibility

MV-10, MV-20, MV-200

JVC Compatibility

GR-DVL 20, DVL 30, DVL 40, DVL 150
 GR-DVL 257
 GR-DVL 9200, DVL 9500
 GR-DVX 4, DVX 7

Panasonic Compatibility

NV-DA1B, DS1B, DS5B
 NV-DS8B, DS11B, DS12B, DS15B, DS99B
 NV-DS25B, DS33B, DS35B, DS55B
 NV-DS77B, NV-DX100B, NV-EX1B,
 NV-EX3B
 NV-EZ30B

Sony Compatibility

DCR-PC1E, PC2E, PC3E, PC4E, PC5E, PC6E
 TRV5E, TRV6E, TRV7E, TRV8E, TRV10E, TRV11E, TRV15E,
 TRV17E
 DCR-TRV890E
 DCR-VX700E
 DCR-TR7000E, TR7100E, TR8000E, TR8100E
 DCR-TRV110E, TRV210E, TRV310E, TRV410E, TRV510E
 DCR-TRV120E, TRV125E, TRV220E, TRV320E, TRV420E,
 TRV520E, TRV725E

Name	Product Code	For
DV-INabler C	MI-DVINC	Canon
DV-INabler J	MI-DVINJ	JVC
DV-INabler P	MI-DVINP	Panasonic
DV-INabler S	MI-DVINS	Sony

Key Features

Activates DV-IN on your camcorder

The DV-IN functionality of most DV camcorders sold in the European Union is disabled. DV-INabler allows you to reactivate this feature

Extremely easy to use, requires no computer - Simply press the DV-INabler's button for a few seconds and your camera will be DV-IN enabled!

Simply connect DV-INabler to the COM port of your Camcorder and press the button to perform the enablement process

Can act as a Record/Pause button for your camera

A useful feature if you use a tripod with your camcorder

DV-IN enablement process can be reversed very easily in a few seconds

Contacting Miglia Technology

Miglia Technology
 1, The Old Silk Mill, Brook Street
 Tring, HP23 5EF
 United Kingdom

Tel: +44 (0)870 747 2988, Fax: +44 (0)870 747 2989

E-mail: info@miglia.com

Web: <http://www.miglia.com>

Note: There are four versions of DV-INabler, one for each supported brand. You can enable DV-IN only on a single camcorder with DV-INabler.